



**WASTE  
TREATMENT  
PONDS HAD  
THEIR  
BEGINNING  
IN ENGLAND  
IN THE  
MID-1800's**

# WASTE TREATMENT PONDS

RAW WASTE



STABILIZATION  
POND

PRIMARY  
TREATMENT



OXIDATION  
POND

# WASTE TREATMENT PONDS

SECONDARY  
TREATMENT



POLISHING  
POND

**PONDS HAVE BEEN  
DESIGNED AND BUILT IN  
THIS COUNTRY FOR ABOUT  
60 YEARS**

**• NO EXPENSIVE EQUIPMENT**

**• EASY TO CONSTRUCT & OPERATE**

**• LOW ENERGY USAGE/ LOW SLUDGE**

**• WILDLIFE HABITAT/REFUGE**

**ANOTHER IMPORTANT  
FEATURE OF A WASTE  
TREATMENT POND IS  
ITS ABILITY TO  
EASILY ADJUST TO  
VARIABLE ORGANIC  
LOADS**

# DISADVANTAGES OF PONDS

- REQUIRE LARGE LAND AREA

- MAY EMIT ODORS


- MAY CONTAMINATE GROUNDWATER

- MAY HAVE HIGH SUSPENDED SOLIDS IN THE EFFLUENT

# THREE BASIC TYPES OF PONDS



- AEROBIC
- ANAEROBIC
- FACULTATIVE

# AEROBIC PONDS






# ANAEROBIC PONDS



- DEVOID OF OXYGEN
- 6 to 12+ FEET DEEP
- USUALLY INDUSTRIAL WASTE
- DETENTION TIMES VARY (20-  
? DAYS)

# FACULTATIVE POND




- UPPER PART AEROBIC
- BOTTOM ANAEROBIC  
(LIKE A DIGESTER)
- 3 to 6 FEET DEEP
- MOST COMMON TYPE  
POND

# COMPLETE RETENTION LAGOON

EVAPORATION

INFLUENT



NO  
EFFLUENT

PERCOLATION


$$\text{INFLUENT} = \text{EVAPORATION} + \text{PERCOLATION}$$

# PONDS IN SERIES



CAN PRODUCE A HIGH  
QUALITY EFFLUENT


# PONDS IN PARALLEL




# HOW AN AEROBIC POND WORKS

(PHOTOSYNTHESIS)

OCCURS  
WITHIN  
THE  
FIRST 2.5  
FEET of  
POND  
DEPTH



# AT NIGHT




# NEED TO REMEMBER

IN AN AEROBIC OR  
FACULTATIVE POND:


OXYGEN AND pH go UP  
DURING THE DAY\_and  
DOWN DURING THE  
NIGHT



# OXYGEN SATURATION



SATURATED




SUPERSATURATED

# OXYGEN SATURATION


AT ANY GIVEN  
TEMPERATURE, WATER CAN  
HOLD ONLY SO MUCH  
OXYGEN

<u>TEMPERATURE, °C</u>	<u>mg/L OXYGEN</u>
4	13.1
20	9.1

 SUPERSATURATION

 OXYGEN DEFICIT


DISSOLVED OXYGEN, mg/L



*saturation*

DIURNAL OXYGEN CONC.-LAGOON

# pH in a POND



• INFLUENT pH = 6 to 8


• EFFLUENT pH = 9.5 or more

• High pH usually means high dissolved oxygen (pH tied closely to  $O_2$  production)


**HIGH pH IN POND  
USUALLY MEANS HIGH  
DISSOLVED OXYGEN**

**LOW pH IN POND CAN BE  
CAUSED BY SEPTIC  
WASTE AND INDUSTRIAL  
WASTE**

# HOW AN ANAEROBIC POND WORKS



# HOW A FACULTATIVE POND WORKS




**ALGAE AND BACTERIA  
NUTRIENTS ARE:**



**NITROGEN ( $\text{NH}_3$ ,  $\text{NO}_3$ ,  $\text{NO}_2$ )  
and PHOSPHOROUS ( $\text{PO}_4$ )**



# THE NITROGEN CYCLE



**HIGH CONCENTRATIONS OF  
AMMONIA ( $\text{NH}_3$  > 20 mg/L) IN  
THE EFFLUENT CAN BE HARMFUL  
TO FISH**



# TERM TO REMEMBER!!

## *BIOFLOCCULATION*

THE "CLUMPING" TOGETHER OF  
ALGAE AND BACTERIA WHICH  
SETTLES AND REMOVES  
SUSPENDED AND DISSOLVED  
SOLIDS

# POND PERFORMANCE

## REMOVAL EFFICIENCIES

BOD/SS      90 - 95%




FECAL COLIFORM      99%

# SURFACE LOADING RATES

<u>TYPE</u>	<u>lbs BOD/acre/day</u>
AEROBIC	<u>60</u> - 200
ANAEROBIC	<u>200</u> - 1000
FACULTATIVE	15 - 30
TERTIARY	5 - 15
MECH. AERATED	20 - 400

# LOCATION AND PROTECTION OF PONDS

- SAME AS ANY WWTP:  
DOWN-GRADIENT (if possible)
- ORIENTED WITH RESPECT  
TO THE WIND




**PREVAILING  
WIND**

**ORIENT THE POND  
TO PREVENT DIKE  
EROSION BUT TO  
MAXIMIZE SCUM  
DISPERSION AND  
RE-AERATION**

# FACTORS AFFECTING PONDS

## -PHYSICAL-




### WIND:

- CREATES MIXING
- AFFECTS  
DISSOLVED OXYGEN



# FACTORS AFFECTING PONDS

## -PHYSICAL-



### TEMPERATURE

- LOW WATER TEMP  
HOLDS MORE OXYGEN
- HIGH WATER TEMP  
INCREASES  
MICROBIAL ACTIVITY

# FACTORS AFFECTING PONDS

## -PHYSICAL-



### SUNLIGHT

- ESSENTIAL FOR ALGAE GROWTH

*SHORT-  
CIRCUITING*

# FACTORS AFFECTING PONDS

## -CHEMICAL-

- ORGANIC MATERIAL
- pH
- TYPE OF SOLIDS


# FACTORS AFFECTING PONDS

## -BIOLOGICAL-



- TYPE(S) OF ALGAE
- ACTIVITY OF ORGANISMS
- NUTRIENTS AVAILABLE
- TOXICANTS

# POND START-UP



ADD 1 to 2 FEET OF WATER TO  
THE POND BEFORE ANY  
WASTEWATER TO PREVENT ODORS  
AND TO HELP THE POND GET  
STARTED. ALSO KEEP pH >7.5  
(ADD SODA ASH)

# SAMPLING AND ANALYSES

- FOR POND CONDITION: pH and dissolved oxygen - - 5/week (night?)

- TEMPERATURE, pH, DISSOLVED OXYGEN & CHLORINE RESIDUAL—SHOULD BE ANALYZED IMMEDIATELY (GRAB SAMPLE)

# DISSOLVED OXYGEN (D.O.)

- GOOD INDICATOR OF ACTIVITY  
(IN AEROBIC POND)

- BY WATCHING D.O., OVERLOADING  
CAN BE DETERMINED

- LOW D.O. = HIGH BOD

# SAMPLING AND ANALYSES

*FOR TREATMENT EFFICIENCY:*

- BOD, SUSPENDED SOLIDS,  
(COMPOSITE SAMPLES)

- COMPOSITE SAMPLES SHOULD  
BE REPRESENTATIVE




# COMPOSITE SAMPLES

2 TYPES OF COMPOSITES;  
WITH RESPECT TO...

A. TIME &  
FLOW




B. LOCATION



# OPERATION & MAINTENANCE

## SCUM CONTROL



TO PREVENT  
CRUSTING (LOSS OF  
SUNLIGHT) AND TO  
DESTROY A HABITAT  
FOR PATHOGENS  
AND VECTORS




# OPERATION & MAINTENANCE

## ODOR CONTROL

- USUALLY CAUSED BY OVERLOADING OR POOR MAINTENANCE

- SOMETIMES A PROBLEM IN SPRINGTIME—MIGHT HAVE TO AERATE OR ADD SODIUM NITRATE



# OPERATION & MAINTENANCE

IF HYDROGEN SULFIDE ( $H_2S$ )  
ODOR IS PRESENT, RAISING  
THE pH ABOVE 8.5 (THE pH OF  
A NORMALLY OPERATED POND)  
WILL LIKELY TAKE CARE OF  
THE PROBLEM

# OPERATION & MAINTENANCE

**WEED &  
INSECT  
CONTROL**


**PROBLEM: ALTERS  
WIND MOVEMENT  
AND PROVIDES A  
VECTOR HABITAT**

**•KEEP >3 ft of WATER TO PREVENT  
CATTAIL & TULE GROWTH (LIMITS SUNLIGHT)**

**•REMOVE EMERGENT GROWTH BY HAND -  
USE HERBICIDES AS LAST RESORT**




**CATTAILS**



# MOSQUITOES CAN BE A PROBLEM

EGG RAFTS CAN  
ATTACH TO SCUM OR  
EMERGENT  
VEGETATION




# MOSQUITOES SOMETIMES CONTROLLED BY...



GAMBUSIA (MOSQUITO  
FISH)







# CHIRONOMID MIDGE

(chir-AHN-ah-mid)

2 CHOICES: LIVE WITH THEM or  
USE A PESTICIDE

# OPERATION & MAINTENANCE

## DUCKWEED



DUCKWEED CAN BLOCK  
SUNLIGHT AND HARBOR  
VECTORS & TOXINS



• DUCKWEED CAN BE CONTROLLED  
WITH GOOD WIND CIRCULATION

USE PESTICIDES AS A LAST  
RESORT

# OPERATION & MAINTENANCE

DIKE / LEVEE  
VEGETATION



MOW REGULARLY and CONTROL  
BURROWING ANIMALS

DO NOT ALLOW ANIMALS TO GRAZE!


# LEVEE CONTROL

•IF ERODING, PROTECT WITH RIP-RAP  
or SEMI-PORUS PLASTIC MEMBRANE



RIP RAP ALSO  
KEEPS THE  
VEGETATION  
GROWTH DOWN

**PONDS SHOULD BE FENCED TO  
KEEP OUT LIVESTOCK AND TO  
DISCOURAGE TRESPASSERS**



**WASTEWATER  
TREATMENT  
PLANT**

**NO  
TRESPASSING**

# COMMON PROBLEMS

PROBLEM

CAUSE (?)

ODOR

- BOD OVERLOAD
- POOR AERATION/  
MIXING

# ODOR CONTROL

- REDUCE BOD LOAD BY TAKING POND OFF-LINE AND GRADUALLY RE-LOADING THE UNIT

- RECIRCULATE FROM AN AEROBIC POND (about 17%) TO RESTORE OXYGEN IN "SICK" POND

- USE MECHANICAL AERATOR or ADD SODIUM NITRATE



# COMMON PROBLEMS

PROBLEM

CAUSE (?)

POOR BOD  
REMOVAL

- OVERLOADED
- SHORT-CIRCUITING
- SNOW/ICE COVER
- RECENT TEMP DROP
- ALGAL BLOOM

# COMMON PROBLEMS

PROBLEM

CAUSE (?)

HIGH  
SUSPENDED  
SOLIDS IN  
EFFLUENT

- ALGAL BLOOM
- TOO MUCH MIXING/SHORT-CIRCUITING
- SEASONAL OVERTURN

# ALGAE BLOOM



CAUSES ODORS and CAN BE TOXIC

# PREDOMINATE TYPES OF ALGAE

- GREEN
- BROWN
- RED
- CYANOBACTERIA  
(BLUE-GREEN)

# ALGAL CONTROL MEASURES


- FILTER the EFFLUENT

- CENTRIFUGE the EFFLUENT

- COPPER SULFATE ( $\text{CuSO}_4$ )

- WATER HYACINTH

- ALGAE "EATERS" - - DAPHNIA



**DAPHNIA**  
**AKA WATER**  
**FLEAS**

**WILL FEED**  
**ON ALGAE**

# COMMON PROBLEMS

PROBLEM

CAUSE (?)

POOR FECAL  
COLIFORM  
REMOVAL

- POOR  
DISINFECTION
- INCREASE IN  
CHLORINE  
DEMAND IN THE  
EFFLUENT

# COMMON PROBLEMS

PROBLEM

CAUSE (?)

HIGH pH

• ALGAL BLOOM

LOW pH

• SLUDGE  
ACCUMULATION

• EXCESSIVE  
NITRIFICATION  
( $\text{NH}_3 \rightarrow \text{NO}_3$ )



# O&M GOAL FOR PONDS

- DEEP GREEN COLOR (high pH & DO)

- MEET NPDES DISCHARGE LIMITS

- NO EMERGENT VEGETATION IN THE WATER; NO TALL WEEDS ON THE BANK

- EROSION CONTROL ON DIKES

# VISUAL INDICATORS

pH

>9

<7

COLOR

GREEN

YELLOW -  
GREEN

pH is lower in the morning ( $\text{CO}_2$  produced by bacteria @ night)

pH is higher in the afternoon

# O&M GOAL FOR PONDS

- CLEAN INLET/OUTLET STRUCTURES

- MECHANICAL EQUIPMENT IS WELL MAINTAINED

- NEAT & COMPLETE RECORDS ON PLANT OPERATION and MAINTENANCE

# MECHANICALLY AERATED PONDS (BEHAVE LIKE AN ACTIVATED SLUDGE PLANT)



# AERATORS



**DIFFUSED-  
AIR**



# AERATORS



**SURFACE MOUNTED**

# MECHANICALLY AERATED PONDS

- PROVIDES ADDITIONAL AIR  
(NIGHT, WINTER, WHEN  
OVERLOADED)

- CREATES AN "ACTIVATED  
SLUDGE-LIKE" PROCESS

# AERATOR MAINTENANCE

- MAKE SURE AERATOR IS TURNED OFF AND LOCKED-OUT

*CLEANING DIFFUSORS, REMOVING DEPOSITS, KILLING SLIME (see text):*

- HYDROGEN CHLORIDE GAS (DANGEROUS)
- HIGH PRESSURE AIR PURGING



**HOW MANY ACRES OF PONDS (WITH  
ZERO DISCHARGE) WOULD BE NEEDED  
TO SERVE 650 PEOPLE IN So. NEW  
MEXICO?**

ASSUME NO PERC & 60" per year EVAP

$$(650 \text{ cap} \times 100 \text{ gpd/cap}) / 7.48 \text{ gal/ft}^3 = 8690 \text{ ft}^3/\text{day}$$

$$8690 \text{ ft}^3/\text{day} \times 365 \text{ day/yr} \times \text{yr}/60 \text{ in} \times 12 \text{ in/ft}$$

$$= 634,370 \text{ ft}^2$$

$$634,370 \text{ ft}^2 / 43,560 \text{ ft}^2/\text{acre} = 14.6 \text{ acres}$$

(plus allowances for rain)

# DESIGN CRITERIA

DETENTION TIME:

$$\frac{\text{POND VOLUME, acre-ft}}{\text{INFLUENT RATE, acre-ft/day}}$$

• HYDRAULIC LOADING:

$$\text{INCHES/DAY}$$

• POPULATION LOADING:

$$\text{PERSON/ACRE}$$

# DESIGN CRITERIA

- ORGANIC LOADING:


LBS BOD/DAY/ACRE

ORGANIC LOADING:

(BOD mg/L) (FLOW, MGD) (8.34 #/gal)  
POND AREA, acres

# ARITHMETIC REVIEW

LENGTH



WIDTH

$$\text{SURFACE AREA} = L \times W$$

$$1 \text{ ACRE} = \underline{43,560} \text{ SQ-FT}$$

*REMEMBER....*

EACH PERSON  
DISCHARGES 75-100  
GALLONS of  
WASTEWATER PER DAY

0.2 POUNDS BOD/PERSON

# CALCULATING BOD LOADING

$$\begin{aligned} &\text{CONCENTRATION, ppm} \times \\ &\text{FLOW, MGD} \times \underline{8.34} \text{ lbs/gal} = \\ &\text{POUNDS/DAY} \end{aligned}$$

What is the daily BOD loading, in pounds given the following:  
FLOW=300,000 gal/day;  
BOD = 225 mg/L?

**BOD LOADING =**

$$225 \text{ ppm} \times 0.3 \text{ MGD} \times 8.34 \text{ lbs/gal} \\ = \underline{563} \text{ lbs/day}$$

**AT AN ALLOWABLE LOADING OF  
35 lbs-BOD per day/acre, how large  
of a pond is necessary?**

$$\frac{563 \text{ \#/day}}{35 \text{ \#/day/acre}} = \underline{16} \text{ acres}$$